


DALVEY
— 1897 —

CLIPPER CLOCK

Elegant, compact and exuberant, the Clipper Clocks are as well suited to travel as they are to adorning a desk or bedside table; their five vibrant colourways each have a unique and markedly differentiated character.

- (Fig.i) To display the Clipper Clock in the upright position simply swing open the clock body from the ring.



INSTRUCTIONS FOR USE


TIME SET

(turn anti-clockwise)

ALARM
ON/OFF

ALARM
TIME SET

(tolerance +5 or -5 minutes turn clockwise)



- (Fig.ii) Open the battery cover on the back and remove the small protective tab from the battery (Battery LR44). The controls for setting the time and alarm are also found here. The time set control knob should be adjusted in an anti-clockwise rotation only, and the alarm time set control knob in a clockwise rotation only.



This product conforms with
EMC Directive 89 / 336 / EEC

