

DALVEY
— 1897 —

FULL HUNTER POCKET WATCH

INSTRUCTIONS FOR USE

- **(Fig.i)** To open case, hold the watch flat in the palm of the hand and press the button in the centre of the crown. The lid will then pop open.
- This button should also be pressed when closing the case to save wear on the catch.

Please note: Pocket watch lids do not open beyond 85° due to the design of the discreet hinge mechanism. If the lid is forced open beyond 85° it will damage the watch and invalidate its warranty.

TIME SETTING

- **(Fig.ii)** To adjust the time, pull the crown wheel gently out until it clicks once.
- Rotate until the correct time shows. Push the crown wheel in to restart the watch.

Please note: Mechanical pocket watches should be wound every 36 hours, but care should be taken not to overwind.

(Fig.i)



(Fig.ii)



RELIABILITY, REFINEMENT & STYLE

- The precision engineered Full Hunter Pocket Watch incorporates a high quality mechanical movement with a separate seconds dial.
- The spring loaded lid protects the watch face and pops open at the press of a button.
- All pocket watches are supplied with a quality pocket watch chain.
- As with all Dalvey products, the pocket watches come with a Dalvey guarantee.